



Collection of URINE samples:

Use the cobas[®] PCR Urine Sample Kit for Urine samples


SPECIMEN COLLECTION

COLLECT: Prior to sampling, the patient should not have urinated for at least one hour. Given that collection of larger volumes of urine may reduce test sensitivity, please direct patient to provide first-catch urine (approximately 10-50mL of the initial urine stream) into a Green Top Urine Jar.


NOTE: For best results, female patients should not cleanse the labial area prior to collection




1. PIPETTE: Immediately transfer the urine into the cobas PCR Media tube using the provided disposable pipette. NOTE: If the urine specimen cannot be transferred immediately, it can be stored at 2°C to 30°C for up to 24 hours.



2. TRANSFER: The correct volume of urine has been added when the fluid level is between the two black lines on the tube label.



3. CAP: Tightly re-cap the cobas[®] PCR Media tube.



4. MIX: Invert the tube 5 times to mix. The specimen is now ready for transport.